

Warranty

Brilliant Lighting warrants this product against defects in manufacture and workmanship for a period of 12 months from date of purchase. Warranty does not include damage or loss arising from incorrect installation, operation or maintenance of this product, damage caused through modification, or incorrect installation.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if goods fail to be of acceptable quality and the failure does not amount to a major failure.

Any claim under this warranty must be made within 12 months of the date of purchase of the product.

Refer to our website brilliantlighting.com.au for terms and conditions and warranty claims.

This warranty is given by:

Brilliant Lighting (Aust) Pty. Ltd.

ABN 37 006 203 694

956 Stud Road Rowville, VIC 3178

Phone: 03 9765 2555

Email: warranty@brilliantlighting.com.au

MADE IN CHINA

Warning

1. To prevent injury, this apparatus must be separately attached to the wall in accordance with the installation instructions.
2. For indoor and outdoor use (when used with suitable weatherproof powerpoint).
3. Please do not use in your bathroom.
4. Please make sure the smart plug is not overloaded. Working power cannot be higher than the rated current.
5. If the smart plug is used to operate appliances intended for supervised use (eg heater), ensure that the appliance instructions are followed and the appliance is physically supervised whilst on. Do not allow any cables, furnishings, flammable materials or other items to come in contact with any surface of a heater.

Disposal

Please dispose of this packaging and product thoughtfully once it has passed its useful life. When your smart device comes to the end of its life or you choose to update or upgrade it, please do not dispose of it with your normal household waste. Please recycle where facilities exist.

When disposing of this fitting, check with your local authority for suitable options.

Troubleshooting

Problem:

Smart device does not switch ON

Possible Cause

No Mains Power

Suggested Solution

Check connections, fuses and switches

Problem:

Cannot link smart device with BrilliantSmart App

Possible Cause

1. Modem signal weak

Place device and modem closer together

2. Router/modem/smart phone firewall is enabled

Disable firewalls on all devices

3. Internet connection is down

Contact your provider

4. BrilliantSmart App not installed correctly

Remove App and re-install

For any other problems connecting your smart device to BrilliantSmart App please visit:
www.brilliantsmart.com.au/faqs

*Plug must be plugged into a weatherproof powerpoint.

Brilliant Lighting

956 Stud Road
Rowville Vic 3178 Australia
www.brilliantlighting.com.au

Australian Sales

T 03 9765 2555

T 1800 817 754 (interstate only)

F 03 9763 0277

E warranty@brilliantlighting.com.au

New Zealand Sales

T 09 974 9618

E sales@brilliantlighting.co.nz



IP44
WEATHER
RESISTANT

TIMER &
SCHEDULING

DIY

DESIGNED FOR
OUTDOOR USE*



WiFi Outdoor
double plug

20924



INSTRUCTION MANUAL



Box Content

WiFi Outdoor double plug x 1
Instruction Manual x 1



Manual control button



1

Technical Specifications

Model No: 20924
Working voltage: 240VAC
Support Max power: 10A, 2400W
Standby Power: <0.9W
IP Rating: IP44
Size: 122 x 104 x 62mm
Weight: 246gm
Warranty: 1 year
Security: Mac Encryption; WEP/WAPI/TKIP/AES
WiFi Standard: IEEE802.11b/g/n
System Req's: iOS 8.0 or higher, Android 4.1 or higher

2


Connect to your WiFi

Ensure your mobile phone is connected to your 2.4GHz WiFi network.

Your mobile phone and smart device needs to be within 2 bar range of your WiFi router.

Download the BrilliantSmart App

Please download the free BrilliantSmart App from the App store or Google Play store, or scan the QR code below.



Register the BrilliantSmart App

Open the BrilliantSmart App.


For new users, register a new account or if existing user, login with your user name and password.

3

Configure your BrilliantSmart App

Setting up your Home

You can setup multiple homes or locations. Click **'Add Home'** button. Or Click on **'Home'** top left if you are adding or modifying details then **'Home Management'** to setup your home(s), add or rename rooms and share devices.




Add your Smart WiFi Plug to your App

1. Insert your Smart WiFi Outdoor double plug into a power point and turn on the power. The smart plug will automatically start flashing and be ready to pair with the BrilliantSmart App.

2. Open the BrilliantSmart App, tap **'Add Device'** (if empty room) or **'+'** to add your Smart device

3. Select **'Electrical Outlet'** in the list of devices. If the smart plug is blinking rapidly then press **'Confirm indicator rapidly blink'**. It will start connecting.

If the plug has not automatically starting flashing, turn the power OFF for 10 seconds and turn ON again. Press and hold the manual control button for 5 seconds and release. Press button once again and now the red light will blink rapidly (2 times per second).




4

4. Enter your home WiFi password.



Connection will now begin.




5. Once connected you'll get a menu **'Device added successfully'**.

Select the room device and press **'Done'**.

You can click on the pen to change the device name.

6. Now you can plug in a light or any other device into your Smart WiFi Outdoor double plug. This will be controlled by your App.



Go to www.brilliantsmart.com.au for full instructions and features

5